

# airTools™

## BROADCAST SOLUTIONS



## User's Guide

# 6000

**BROADCAST  
AUDIO DELAY**



## Before You Begin

### What Ships in the Box

- 📦 A 6000 hardware device.
- 📦 A detachable power cord.
- 📦 This User's Guide.

### Getting Help

If you have questions beyond the scope of this user's guide, contact our Customer Support Group in the following ways:

**Tel:** +1 (425) 778-7728

8:00 am to 4:30 pm

Monday through Friday,

Pacific Time

**Web:** <http://www.SymetrixAudio.com>

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



This Class B Digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations

Cet appareil numérique de la classe B respecte toutes les Exigences du Règlement sur le matériel brouilleur du Canada.

### Important Safety Instructions.

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water. This apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install only in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 This apparatus shall be connected to a mains socket outlet with a protective earthing connection. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug cord is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



	<b>CAUTION</b> RISK OF ELECTRIC SHOCK DO NOT OPEN	
<b>WARNING:</b> TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE		
<b>AVIS:</b> RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR		

SEE OWNERS MANUAL. VOIR CAHIER D'INSTRUCTIONS.  
No user serviceable parts inside. Refer servicing to qualified service personnel.  
Il ne se trouve à l'intérieur aucune pièce pouvant être réparée l'utilisateur.  
S'adresser à un réparateur compétent.

- ! **The lightning flash** with arrowhead symbol within an equilateral triangle is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product (i.e. this User's Guide).
- ! **CAUTION:** To prevent electric shock, do not use the polarized plug supplied with the unit with any extension cord, receptacle, or other outlet unless the prongs can be fully inserted.
- ! **Power Source:** The AirTools 6000 hardware uses a switching power supply that automatically adjusts to the applied voltage. Ensure that your AC mains voltage is somewhere between 100-240 VAC, 50-60 Hz. Use only the power cord and connector specified for the product and your operating locale. A protective ground connection, by way of the grounding conductor in the power cord, is essential for safe operation. The appliance inlet and coupler shall remain readily operable once the apparatus has been installed.
- ! **User Serviceable Parts:** There are no user serviceable parts inside this Symetrix product. In case of failure, customers inside the U.S. should refer all servicing to the Symetrix factory. Customers outside the U.S. should refer all servicing to an authorized Symetrix distributor. Distributor contact information is available online at: <http://www.SymetrixAudio.com>.

### Introduction

### Introduction

Thank you for your purchase of the **AirTools™ model 6000 Broadcast Audio Delay**, engineered by Symetrix. The 6000 has been designed to give broadcasters unequalled performance combined with ease of use and reliability. This manual will guide you through the installation and operation of the 6000, and provide valuable tips on how to interface with other equipment in your studio or control room.

The 6000 gives the host or producer of a talk show the power to prevent the broadcast of unwanted profanities or comments from guests, hosts or telephone callers. As the program begins, the 6000 gradually and unobtrusively delays or “stretches out” the program until up to 40 seconds of 20 kHz bandwidth stereo audio is stored in memory. When a person says something the host or producer does not think appropriate for the broadcast, he or she presses the DUMP button and a user preset length of memory is cleared, thereby preventing the unwanted audio from reaching the airwaves. Meanwhile, the host releases the offending caller from the telephone line and proceeds with the program. After the DUMP button has been pressed, the 6000 automatically begins to stretch (time expand) the program audio again until the user preset length of delay is attained.

Several minutes in advance of the end of the talk show, the host or producer presses the EXIT DELAY button and the 6000 begins to time compress the program audio until there is nothing left in the 6000's memory (zero seconds delay). At this point the program is back in “real time.”

A unique feature of the 6000 is the COUGH button, which allows the host to make impromptu interruptions in the program for up to 40 seconds while keeping the audience unaware of the break. When the COUGH button is pushed, the 6000 plays from memory while the button is held in. As soon as the button is released, the 6000 automatically begins to refill the memory. The host can cough, have a quick drink of water, or make a comment to the producer or engineer without any perceptible program interruption.

The 6000 uses the latest in delta-sigma conversion technology coupled with advanced digital signal processing (DSP) algorithms. This combination produces a product that meets or exceeds the highest broadcast standards in terms of low noise, low distortion, and superb signal processing.

The 6000's logical, easy to use control panel holds no hidden surprises. The product is easy to learn and simple to use. In the sections that follow you'll find information on installation, operation, and specific applications of the 6000. We follow this with a troubleshooting guide, warranty and service information, and detailed specifications.

As with all Symetrix engineered products, the 6000 has been designed and built to the highest standards of the broadcast industry. Our company is committed to excellence in product design, manufacturing, and service. Please do not hesitate to contact us with your questions or comments.



## Front Panel

Item	Description
<b>Bypass</b>	Places the 6000 in either BYPASS or OPERATE modes. In BYPASS mode the incoming signals are directly relay bypassed. In BYPASS mode, the front panel and remote controls have no effect on the operation of the 6000. In OPERATE mode, the incoming signals are processed through the 6000's analog and digital circuitry, and all front panel and remote controls are fully functional.
<b>Previous</b>	Displays the previous menu of the 6000's menu setup hierarchy in the LCD display.
<b>Next</b>	Displays the next menu of the 6000's menu setup hierarchy in the LCD display.
<b>Home</b>	Returns the 6000's LCD DISPLAY to the default operating screen which shows the following information: 1. The top line of the LCD DISPLAY shows the input or output levels for audio channels 1 and 2. Each is labeled with a numeral 1 or 2 respectively to the left. A bar graph meter will display to the right of each numeral. Each bar graph increment represents 1 dB of signal for a peak level metering range of -40 to 0 dBfs. 2. The bottom line of the LCD DISPLAY shows the current operating status of the 6000. For example, 6000 BYPASSED, DELAY REMOVED, ADDING DELAY TIME, REDUCING DELAY TIME, WAITING FOR RELEASE, MUTED, or MAXIMUM DELAY.
<b>Adjust</b>	Scrolls through the available parameters to each setup menu item.
<b>Lcd Display</b>	Shows the current menu item in the setup menu hierarchy as well as its current setting.
<b>A1 Through A4 Leds</b>	Show the state of the four internal relays used for delay automation. The LEDs will be off when the relays are unenergized, green when energized and red when cued to be energized.
<b>Delay Numerical Readout</b>	Shows the length of delay time built up by the 6000 in tenth of a second increments.
<b>Exit</b>	Initiates the gradual reduction of delay time. Once this button is pressed, assuming no other control button is subsequently pressed, the 6000 will proceed to incrementally reduce delay time until a zero delay is achieved.
<b>Start</b>	Initiates the gradual increase of delay time. Once this button is pressed, assuming no other control button is subsequently pressed, the 6000 will proceed to incrementally increase delay time until a user-determined delay time is achieved up to a possible full 40 seconds.
<b>Cough</b>	Pauses the incoming signal while allowing the output signal to play (uninterrupted) from the 6000's memory. The 6000 will continue to play from memory for so long as the button is pressed. When the COUGH button is released, the 6000 resumes recording into memory and "splices out" the silence created while the button was pressed. The 6000 then begins to rebuild the delay time used while the COUGH button was pressed. The listener will be aware of a program interruption if and only if the button is held for a time exceeding the time in memory, in which case the input is muted.
<b>Dump</b>	Erases a user-determined portion of the 6000's delay memory. The 6000 will then proceed to splice back together everything except the erased audio. Next, if no other control button is subsequently pressed, the 6000 will proceed to incrementally increase delay time until the user-determined second delay is again achieved. See <b>Operation</b> for further explanation of the DUMP function and its delay length settings.

Rear Panel



Rear Panel

Item	Description
AC INPUT	Accepts nominal AC power sources of 100 - 240 volts see <b>Specifications</b> for voltage tolerance ranges. See <b>Installation</b> for details on the detachable (IEC) power cable.
REMOTE CONTROL and INDICATORS	Provides a way to connect to the AirTools RC-6000 or a user supplied remote control and/or indicator panel. AND INDICATOR See pages 12-13 for details.
AUTOMATION	Provides a way to interface with the four internal relays used for delay automation..
ANALOG OUTPUT	Electronically balanced, line level, low impedance outputs. Pin 1 is ground. Pin 2 is high. Pin 3 is low. LEFT and RIGHT
ANALOG INPUT	Electronically balanced, line level, bridging inputs. Pin 1 is ground. Pin 2 is high. Pin 3 is low. LEFT and RIGHT

## AC Line Connection

A sticker on the rear of the unit indicates the nominal voltage setting for the unit as it left the Symetrix factory. If this does not correspond to the voltage setting for your locale then do not attempt to apply power to the 6000. Instead, return the unit to your local Symetrix distributor for modification.

The 6000 is shipped from the Symetrix factory with a detachable AC power cable (IEC standard) included. Depending on the intended destination, the power plug is either the US type (intended for 115 VAC use), or the Europlug type. If the power cable's plug is not right for your locale, then please contact your local Symetrix distributor for the proper cable.

Once you have determined that the 6000's operating voltage matches that of your locale and you are ready to begin, follow these steps:

1. Plug the socket end of the power cable into the recessed AC power receptacle on the back of the 6000.
2. Plug the other end of the power cable into a three-hole grounded outlet or power strip.



**WARNING:** The 6000 is intended to be electrically grounded. It has been provided with a three-wire grounding plug - a plug that has a third (grounding) pin. This plug will fit only a grounded AC outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact a licensed electrician to replace the outlet with a properly grounded outlet. Do not defeat the purpose of the grounding plug!

### ! IMPORTANT NOTICE !

The wiring diagram on this (and the following) page are included for information purposes only.

Symetrix can not anticipate exactly what connection is needed at the non-6000 end of the cable. It is the user's responsibility to determine what connection is needed.

In addition, Symetrix accepts no responsibility for injury or damage caused by user created wiring.


## Mounting in an Equipment Rack

The 6000 occupies one rack space (1U) in a standard equipment rack with a width of 19" (48.3 cm), a depth of 7.8" (19.8 cm), and a height of 1.75" (4.45 cm). Allow at least 4" (10.16 cm) behind the unit for the protrusion of connectors. We recommend you take care not to mount the 6000 next to devices that emit large electromagnetic fields, such as audio power amplifiers. To do so may comprise the noise performance of the 6000. The 6000 has been designed to conform to mechanical guidelines as described in EIA Standard RS-310-C and IEC Recommendation 297.


## Analog Audio Input Connections

The 6000's audio input connections are via standard female XLR jacks located on the rear panel. For optimum system performance we recommend that the 6000 be connected to balanced signal sources. If this is not practical in your situation, then you may connect to unbalanced sources. The following diagram illustrates recommended cable wiring practices.


### XLR Female to Male Plug [balanced]



### TRS 1/4" Plug to XLR Male Plug [balanced]



### TS 1/4" Plug to XLR Male Plug [unbalanced]






## Connections and Levels


### Analog Audio Output Connections

The 6000's audio output connections are via standard female XLR jacks located on the rear panel. For optimum system performance we recommend that the 6000 be connected to balanced devices. If this is not practical in your situation, then you may connect to unbalanced devices. The following diagram illustrates recommended cable wiring practices.


#### XLR Female to Male Plug [balanced]



#### XLR Female Plug to TRS 1/4" Plug [balanced]



#### XLR Female Plug to TS 1/4" Plug [unbalanced]




### Signal Levels

The 6000 has been designed to operate at standard nominal broadcast signal levels of either 0 VU = +4 dBu or 0 VU = +8 dBu. To provide even more flexibility, the 6000 can also operate at -10 dBu and 0 dBu. The 6000's operating level can be adjusted by navigating to the NOMINAL INPUT and/or OUTPUT LEVEL pages in the setup menus on the LCD display. A full discussion of the setup menus can be found on page 7.

### Typical System Hookup Diagram

In most broadcast applications it is recommended that the 6000 be connected between the station's on air console and the station's audio processing equipment. In other words, the console's main stereo (or mono) output bus should connect to the 6000's inputs, and the 6000's outputs should feed the "down stream" signal processing.

### Typical 6000 System Hookup





## Remote Control & Indicators Connector

This DB-25 connector allows you to remotely control the EXIT DELAY, START DELAY, COUGH and DUMP functions of the 6000. You can also remotely view the status items DELAY INACTIVE, DELAY ACTIVE, HALF delay accumulated and WHOLE delay accumulated. This connector interfaces directly with the AirTools RC-6000 Remote Control. Alternatively, you can use the pinout provided in Page 12 to wire your own remote and indicators.

## Automation Connector

This DB-25 connector provides a way to interface with the four internal relays used for delay automation. The 6000 has four internal relays that may be independently used to control station automation events. The relay closures (outputs) are triggered by input closures that can be either manual (a momentary switch closure) or electrical (TTL logic low). When an input closure takes place the audio entering the delay at that moment is 'tagged'. When the tagged audio reaches the output of the delay it's corresponding relay closes for a time equal to the length of the input closure.

A typical purpose for automation would be with the use of sync pulses provided by a nationally syndicated broadcast that is being relayed by a local station. The sync pulses can be used to automate the start and exit for the 6000's delay. Another use would allow for a DJ to automate the exit of the delay to coincide with a commercial break allowing the DJ to go on break without having to wait for the delay exit in real time. See Page 12 for pinout.

## Menu Tree

HOME - displays the input/output levels for audio channels 1 and 2 on the top line in a bar graph fashion and displays the current operating status of the 6000 (BYPASSED, DELAY REMOVED, ADDING DELAY TIME, REDUCING DELAY TIME, WAITING FOR RELEASE, MUTED, or MAXIMUM DELAY) on the bottom line. You can get to this default display at any time by pressing the HOME button.

The following table illustrates the 6000's menu tree with the menus and their options listed in the order that they would appear if you were to advance through the menu tree using the NEXT button.

MENU	OPTION
NOMINAL INPUT LEVEL	-10dBu +0 dBu +4 dBu +8 dBu
NOMINAL OUTPUT LEVEL	-10dBu +0 dBu +4 dBu +8 dBu
DELAY TIME	0.0 to 40.0 SECONDS (in 0.1 second increments)
DUMP LENGTH	FIFTH FOURTH THIRD HALF WHOLE

## User's Guide: 6000 Broadcast Audio Delay

### Operation: Menu... continued

MENU	OPTION	DESCRIPTION
ALGORITHM	GAP DETECT	Waits for gaps or pauses in speech and then splices audio. Minimal delay artifacts. Very fast delay build or exit times with speech only program when known maximum build and exit times are not required.
	GAP DETECT & CATCH UP	If gaps do not naturally occur then splicing is forced. Some audible splice artifacts. Use for building and exiting delay with music + speech when known maximum build and exit times are required.
	CONTINUOUS	Continuously forces splicing regardless of program content. Some audible splice artifacts. Use for building and exiting delay with music only when known maximum build and exit times are required.
	PITCH SHIFT	Uses gradual, subtle pitch shifting instead of splicing to increase or decrease delay. Use with music or music + speech when minimal artifacts are required. Build and exit times are predictable.
DELAY RATIO	10:1 to 40:1	Ratio controls the balance of delay build/exit speed vs. overall audio quality. (10:1 = fastest, 40:1 = best quality)
BARGRAPH MODE	PRE DELAY POST DELAY	
AUTOMATION TRIM	EARLY: 300 mS EARLY: 270 mS EARLY: 240 mS EARLY: 210 mS EARLY: 180 mS EARLY: 150 mS EARLY: 120 mS EARLY: 90 mS EARLY: 60 mS EARLY: 30 mS CURRENT DELAY LATE: 30 mS LATE: 60 mS LATE: 90 mS LATE: 120 mS LATE: 150 mS LATE: 180 mS LATE: 210 mS LATE: 240 mS LATE: 270 mS LATE: 300 mS	

This section describes in more detail the 6000's front panel controls and indicators.

## Operational Status

The BYPASS button places the 6000 in either BYPASS or OPERATE modes. In BYPASS mode the incoming analog signals are directly routed (via relays) to the 6000's outputs, thereby bypassing any internal circuitry. In BYPASS mode the front panel and remote controls have no effect on the operation of the 6000. In OPERATE mode, when the delay is active, the incoming signals are processed through the 6000's analog circuitry, and all front panel and remote controls are fully functional.

It is recommended that the 6000 remain in the OPERATE mode at all times. Typically, the 6000 would be placed in the BYPASS mode only if the unit were to malfunction. By design, a loss of mains (AC) power to the 6000 will force the 6000's audio bypass relays to route the incoming signal directly to the 6000's output.

BYPASS status is shown in two places on the 6000. The first is the second line of the home screen on the LCD display. When in BYPASS mode, the status display line will read "6000 BYPASSED." The second place is the 7-segment delay display to the right of the LCD display. When in BYPASS mode, this display will read "BYP".

When the 6000 is in OPERATE mode, the second line of the home screen on the LCD display will show the current operational status. It will read "DELAY REMOVED, ADDING DELAY TIME, REDUCING DELAY TIME, WAITING FOR RELEASE, MUTED, or MAXIMUM DELAY." The 7-segment delay display will show the current delay as numerical value.

## Input/output Level (dB) Display

The INPUT/OUTPUT LEVEL (dB) provides a visual reference of the input (PRE DELAY) or output (POST DELAY) signal. There are separate bar graph displays for each of the two channels and appears on the first line of the home screen in the LCD display. As previously stated, the meters have a range of -40 to 0dBfs. You can use these meters as a guide to help set the input and output operating level of the 6000. Whatever your input levels are, fine adjustment of the input signal must be done ahead of the 6000 (typically with the master bus fader of the broadcast console).

## The Start Button

The START button initiates the gradual increase of delay time. When a radio talk show is to begin, the first action for the operator of the 6000 is to press the green START button. Once this button has been pressed, its light will blink for as long as delay time is increasing. The 7-segment DELAY display on the right end of the LCD screen displays the amount of time in memory at any given instant. From a starting point of zero delay time, the amount of time that it takes to achieve the maximum preset delay depends upon the program material and the maximum delay length set by the user. Once the START button is pressed, assuming no other control button is subsequently pressed, the 6000 will proceed to incrementally increase delay time until the maximum preset delay is achieved.

## The Exit Button

The EXIT button initiates the gradual decrease of delay time. Several minutes in advance of the end of a radio talk show, the operator of the 6000 must press the yellow EXIT button. Once this button is pressed, its light will blink as long as delay time is decreasing. The 7-segment DELAY display on the right end of the LCD screen displays the amount of time in memory at any given instant. The amount of time that it takes to reduce the delay time to zero seconds depends upon the program material and the maximum delay length set by the user. Once the EXIT button is pressed, assuming no other control button is subsequently pressed, the 6000 will proceed to incrementally decrease delay time until a zero delay time has been reached. Once zero delay has been reached, "DELAY REMOVED" will be displayed as a status on the second line of the home screen in the LCD display.

## The COUGH Button

The COUGH button allows the host to make impromptu interruptions in the program for up to the maximum amount of time in memory while keeping the audience unaware of the break. When the COUGH button is pushed and held in, the 6000 plays from memory and mutes incoming audio. As soon as the button is released, the 6000 resumes recording into memory and "splices out" the silence created while the audio was muted. The 6000 then begins to rebuild the delay time used while the

### Operation... continued

COUGH button was pushed. The host can cough, have a quick drink of water, or make a comment to the producer or engineer without any perceptible program interruption. If the COUGH button is pressed for an amount of time exceeding the amount of time in memory, the result will be muted output audio (dead air).

### The DUMP Button

The DUMP button should be pressed as soon as an unwanted comment is heard. Once pressed, a length of audio, as set by the user, in memory is instantly erased. The 6000 will then automatically “splice” around the erased audio so the audience hears no dead air. Please understand that if the talk show host has not given the 6000 time to build up to enough seconds of delay to cover the audio to be dumped, then when he momentarily hits the DUMP button, an obscenity may get on the air. The user has the choice of setting the 6000 to DUMP a FIFTH, FOURTH, THIRD, HALF or the WHOLE memory.

The 6000 also allows the host extra protection in the form of muting if he purposely holds down the DUMP button. Holding down the button long enough would erase the entire memory and mute the output of the 6000 until the DUMP button is released. This provides a “panic button” function for use if all hell breaks loose. The muting function does not activate when the DUMP button is pushed and quickly released.

After a DUMP command the 6000 automatically reenters the last mode it was in either building or releasing memory as appropriate.

### The A1 through A4 Relay Status LEDs

The A1 through A4 LEDs show the state of the four inter-

nal relays used for delay automation. The LEDs will be off when the relays are unenergized, green when energized and red when cued to be energized. The pinout for the DB-25 connector on the rear of the 6000 is on Page 12. One can use this pinout to build a custom automation interface or to interface with existing automation or control equipment.

### The DELAY Time (Seconds) Display

As previously mentioned, the DELAY time display indicates the time duration of the program audio in the 6000's memory at any instant in 0.1 second intervals.

## Solutions to Common Problems

### There is no output signal.

- Check the AC power connections to the 6000.
- Check input and output cables and connections.
- Determine that there really is a signal coming from the source and that it is getting to the 6000.

### Distortion in the digital output signal.

- Check the input signal. Is it overdriving the 6000's input? If so, the INPUT display should indicate so.
- Is the incoming signal already distorted? Listen "up stream" from the 6000 (or manually place the unit in BYPASS mode) to determine that you are feeding it a clean signal.

### Buzz in the output.

- Check input and output connector wiring.
- Check for ground loops between interconnected system equipment.
- Are all system components on the same AC ground?

### Noise (hiss).

- Check input signal levels and input level control settings. The input may be too low in level. If so, boost the signal from your console or input source.
- Is the input signal already noisy? Listen "up stream" from the 6000 to determine if you are feeding it a clean signal.

## Less Common Problems

### The 6000 doesn't power up or doesn't respond properly.

- Consult a qualified service technician or the Symetrix factory.

### The 6000 is not plugged in, but works great anyway.

- Consult your doctor or therapist.

### Remote Indicator & Control Interface Wiring

Many of the 6000's most important control buttons and LED indicators may be wired to a user supplied panel via the DB-25 multi-pin male connector on the 6000's rear panel. The following tables detail the pin functions. The remote switches and LED indicators are electrically isolated from the switches and LEDs on the 6000's front panel, but effectively operate in parallel (i.e. simultaneously) with them. The AirTools RC-6000 is also available to directly interface to this port and provide all of the functions detailed in this pinout.

Remote Panel Switch Pinouts	
Function	Pin #
START	1
EXIT	4
DUMP	7
COUGH	10
BYPASS (Hardware)	14
Switch Common	13

**Note:** The remote switches used should be high quality, momentary, single pole, push button type. All switches should return to pin #13, the switch common point.

**Note:** The BYPASS switch can be either a momentary or toggle. If the switch is on for more than a half second, it is treated as a toggle switch and the 6000 will be forced into BYPASS no matter the current bypass state. Shorter activation results in a bypass on/off toggle.

Remote Panel LED Indicator Pinouts		
Function	LED Cathode	LED Anode
HALF	pin 3	pin 2
WHOLE	pin 6	pin 5
START	pin 9	pin 8
EXIT	pin 12	pin 11
DUMP	pin 16	pin 15
COUGH	pin 18	pin 17
DELAY INACTIVE	pin 20	pin 19
DELAY ACTIVE	pin 22	pin 21

**Note:** Within the 6000, all LED anodes connect to +5 VDC through 220 Ohm resistors and all LED cathodes are grounded. No external resistors are required.

HALF indicates that at least half of the set delay has been built.


WHOLE indicates that the whole set amount of delay is built.

START, EXIT, DUMP and COUGH exactly mirror the respective buttons/indicators on the front of the unit.


**Note:** Pin 19 (DELAY INACTIVE) will have +5 VDC when the current delay = 0.0 seconds.

Pin 21 (DELAY INACTIVE) will have +5 VDC when the current delay is greater than 0.0 seconds.

### Typical remote panel switch wiring



### Typical remote panel LED wiring




Note: The numbers within the circles refer to pins on the 6000's rear panel DB-25 connector which is labelled REMOTE CONTROL & INDICATORS.

Automation connector pinout		
Relay	Function	Pin #
Relay 1	Common	1
	Normally Closed	2
	Normally Open	3
Relay 2	Common	4
	Normally Closed	5
	Normally Open	6
Relay 3	Common	7
	Normally Closed	8
	Normally Open	9
Relay 4	Common	10
	Normally Closed	11
	Normally Open	12
	LED 1 (A1)	13
	LED 2 (A2)	14
	LED 3 (A3)	15
	LED 4 (A4)	16
	LED Return	17
Automation	Auto In 1	18
Button	Auto In 2	19
Closures	Auto In 3	20
	Auto In 4	21
	Auto In Ground	22



## Block Diagram



## Architects and Engineers Specifications

The Broadcast Audio Delay shall be a stereo model whose output is delayed by as much as 40 seconds, thereby allowing the operator to delete or "dump" unwanted audio. The Broadcast Audio Delay shall occupy one rack space (1U).

The inputs shall be active balanced bridging designs terminated with 3-pin XLR (AES/IEC standard wiring) female jacks.

The outputs shall be active balanced designs terminated with 3-pin XLR (AES/IEC standard wiring) male jacks.

Overall frequency response shall be 20 Hz to 20 kHz, +/- 1 dB, measured at +4 dBu output. There shall be no more than 0.01% harmonic distortion measured under the following conditions: +4 dBu input, +4 dBu output, 40 second delay, 1000 Hz test frequency.

When the unit is inoperative (either by loss of power, or via the BYPASS switch), the inputs and outputs shall be wired together.

The Broadcast Audio Delay shall be capable of operating by means of its own built-in power supply connected to 100-240 VAC, 50-60 Hz, 25 W.

The Broadcast Audio Delay shall be a Symetrix, Incorporated model 6000 BROADCAST AUDIO DELAY.

## Technical specifications

### Input/Output Connectors

<b>Inputs</b>	stereo, balanced bridging
<b>Outputs</b>	stereo, electronically balanced
<b>Input Connectors</b>	XLR
<b>Output Connectors</b>	XLR
<b>Polarity</b>	Pin 2 high
<b>Maximum Input Level</b>	+28 dBu
<b>Maximum Output Level</b>	+28 dBu into 100k Ohms
<b>Input Common Mode Rejection</b>	>40 dB @ 1 kHz

### Performance Data

<b>Frequency Response</b>	20 Hz to 20 kHz*, +/- 1 dB at +4 dBu output
<b>Harmonic Distortion</b>	less than 0.01% with +4 dBu input, +4 dBu output, 40 second delay and a 1 kHz test frequency

#### Typical Dynamic Range:

<b>A/D</b>	-110 dB (A-weighted)
<b>D/A</b>	-115 dB (A-weighted)
<b>A/D and D/A Conversion</b>	24-bit sigma delta
<b>Internal Sampling Rate</b>	48 kHz

### Physical

<b>Size (HWD)</b>	1.72 in. x 19 in. x 7.8 in. plus connectors 4.37 cm x 48.30 cm x 19.8 cm
-------------------	---

#### Shipping Weight

11 lbs, 4.9 kg

### Electrical

<b>Power Requirements</b>	100 VAC to 240 VAC, 50 Hz to 60 Hz, 25 W
---------------------------	--

\*A high pass filter is engaged during build and exit modes only when using the gap detect or gap detect+catchup algorithms. During build and exit modes when using either of these algorithms, the frequency response will be down about -3 dB at 100 Hz.

## Warranty and Service

### The Symetrix Limited Warranty

Symetrix, Inc. expressly warrants that the product will be free from defects in material and workmanship for eighteen (18) months from the date the product is shipped from the factory. Symetrix's obligations under this warranty will be limited to repairing or replacing, at Symetrix's option, the part or parts of the product which prove defective in material or workmanship within eighteen (18) months from the date the product is shipped from the factory, provided that the Buyer gives Symetrix prompt notice of any defect or failure and satisfactory proof thereof. Products may be returned by Buyer only after a Return Authorization number (RA) has been obtained from Symetrix. Buyer will prepay all freight charges to return the product to the Symetrix factory. Symetrix reserves the right to inspect any products which may be the subject of any warranty claim before repair or replacement is carried out. Symetrix may, at its option, require proof of the original date of purchase (dated copy of original retail dealer's invoice). Final determination of warranty coverage lies solely with Symetrix. Products repaired under warranty will be returned freight prepaid via United Parcel Service by Symetrix, to any location within the Continental United States. Outside the Continental United States, products will be returned freight collect.

The foregoing warranties are in lieu of all other warranties, whether oral, written, express, implied or statutory. Symetrix, Inc. expressly disclaims any IMPLIED warranties, including fitness for a particular purpose or merchantability. Symetrix's warranty obligation and buyer's remedies hereunder are SOLELY and exclusively as stated herein.

This Symetrix product is designed and manufactured for use in professional and studio audio systems and is not intended for other usage. With respect to products purchased by consumers for personal, family, or household use, Symetrix expressly disclaims all implied warranties, including but not limited to warranties of merchantability and fitness for a particular purpose.

This limited warranty, with all terms, conditions and disclaimers set forth herein, shall extend to the original purchaser and anyone who purchases the product within the specified warranty period.

Symetrix does not authorize any third party, including any dealer or sales representative, to assume any liability or make any additional warranties or representation regarding this product information on behalf of Symetrix.

This limited warranty gives the buyer certain rights. You may have additional rights provided by applicable law.

**Note:** Some Symetrix products contain embedded software and may also be accompanied by control software intended to be run on a personal computer. Said software is specifically excluded from this warranty.

### Limitation of Liability

The total liability of Symetrix on any claim, whether in contract, tort (including negligence) or otherwise arising out of, connected with, or resulting from the manufacture, sale, delivery, resale, repair, replacement or use of any product will not exceed the price allocatable to the product or any part thereof which gives rise to the claim. In no event will Symetrix be liable for any incidental or consequential damages

including but not limited to damage for loss of revenue, cost of capital, claims of customers for service interruptions or failure to supply, and costs and expenses incurred in connection with labor, overhead, transportation, installation or removal of products, substitute facilities or supply houses.

### Servicing Your Symetrix Product

If you have determined that your Symetrix product requires repair services and you live outside of the United States please contact your local Symetrix dealer or distributor for instructions on how to obtain service. If you reside in the U.S. then proceed as follows.

### Return authorization

At the Symetrix factory, Symetrix will perform in-warranty or out-of-warranty service on any product it has manufactured for a period of three (3) years from date of discontinued manufacture.

Before sending anything to Symetrix, please contact our Customer Service Department for a Return Authorization (RA) number. The telephone number is +1 (425) 778-7728. Additionally support is available via the web site: <http://www.SymetrixAudio.com>.

### In-warranty repairs

To get your AirTools 6000 repaired under the terms of the warranty:

1. Call us for an RA number (have the serial number, shipping and contact information and description of the problem ready).
2. Pack the unit in its original packaging materials.
3. Include your name, address, daytime telephone number, and a brief statement of the problem.
4. Write the RA number on the **outside** of the box.
5. Ship the unit to Symetrix, freight prepaid. We do not accept freight collect shipments.

Just do these five things, and repairs made in-warranty will cost you only one way freight charges. We'll pay the return freight.

If you don't have the factory packaging materials, we recommend using an oversize box. Wrap the unit in a plastic bag, surround it with bubble-wrap, and place it in the box surrounded by Styrofoam peanuts. Be sure there is enough clearance in the box to protect the rack ears. We won't return the unit in anything but Symetrix packaging for which we will have to charge you. If the problem is due to operator misuse or error, you will have to pay for both parts and labor. In any event, if there are charges for the repair, you will pay for the return freight. All charges will be COD unless you have made other arrangements (prepaid, Visa or Mastercard).

### Out-of-warranty repairs

If the warranty period has passed, you'll be billed for all necessary parts, labor, packaging materials, and freight charges. Please remember, you must call for an RA number before sending the unit to Symetrix.





6408 216th St. SW | Mountlake Terrace, WA 98043 | USA | Tel: +1 (425) 778.7728 | Fax: +1 (425) 778.7727

**Engineered by Symetrix™**

**AirTools 6000 User's Guide**

© 2008 Symetrix, Inc. All rights reserved. Printed in the United States of America. The information in this document is subject to change without notice. Symetrix, Inc. shall not be liable for technical or editorial errors or omissions contained herein; nor is it liable for incidental or consequential damages resulting from the furnishing, performance, or use of this material. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. Symetrix assumes no responsibility with regard to the performance or use of these products. Under copyright laws, no part of this brochure may be reproduced or transmitted in any form or by any means, electronic or mechanical, without permission in writing from Symetrix, Inc. If, however, your only means of access is electronic, permission to print one copy is hereby granted. The following are either Trademarks or Registered Trademarks of Symetrix, Inc.: Symetrix, AirTools and 6200 Designer. Windows is a Registered Trademark of Microsoft, Inc.. Other product names mentioned herein may be trademarks and/or registered trademarks of other companies and are property of their respective owners.