



INSTALLATION INSTRUCTIONS MRC 1600 to MRC 1620 CONVERSION

1. Remove Telco or Subcarrier input and output boards from existing CPU board.
2. Remove CPU Board.
3. Install new CPU Board. Eproms are labelled "CT" for studio CPU and "RT" for transmitter CPU; they should be installed accordingly.
4. Remove Communications I/O Board on the back panel and replace with the new board.
5. The longer cable from the Communications I/O Board connects to P6 on the CPU Board.
6. Install Telco Boards on new CPU.
7. Do the same steps for both Control Terminal and Remote Terminal.