



= Nominal DC Voltages
Use VTVM or FETVM

All transistors must have
0.6V nominal forward
emitter to base bias.

- F ECR 643
- E ECR 243
- D ECR 234
- C ECR 105
- B ECR 50
- A ECR 43

1008A-5	1018	FUNCTION
1	4	INPUT
2	5	INPUT
3	1	GND
4	2	GND
5	—	N.C.
6	6	OUTPUT
7	3	-27VDC



TITLE
1018
MICROPHONE PREAMP
(401 BOARD)

DRAWN. *SMU* DATE. 8-28-69

APPD. *RKO* DATE. 2-9-70

SHT OF

1 1

DWG. NO.

S-11G