

# NOTES

- When limiter is used in transmitter the following changes must be made to the exciter board:  
 Remove A1 and R9, replace R10 with jumper, change R11 to 76.8 ohm, 1%, 1 watt metal film.

