

JUMPER W20/21
Interrupt Audio
to Mic Preamp

JUMPER W18/19
Unbalanced Pre-Fader
Patch Point

JUMPER J5/6
Factory Use for
Rotary Fader
Console Only

JUMPER J9/10/11/12
Select for Mic Preamp
Insert for "A" Input

JUMPER J7
Enable/Disable
Monitor Mute & On
Air Light Control

JUMPER W24
Enable/Disable
Timer Reset

**TO ADD MUTE & AIR LIGHT
FEATURE ON LINE INPUT CARD**
Install D3 = 1N4148 Diode
Install Q4 = VP0610L FET

JUMPER W23
Enable/Disable
Monitor and Cue
Mute and On Air
Light Control

MX MODULE JUMPER & MUTING CONTROL INFORMATION



LPB Communications, Inc.

960 Brook Road - Unit 5 - Conshohocken, PA. - 19428
Phone - 610.825.4100 Fax - 610.825.4047