



J1 - STD BUS EDGE CONN

- J1-1 +5 VDC
- J1-2 +5 VDC
- J1-3 LOGIC GND
- J1-4 LOGIC GND
- J1-53 AUX GND
- J1-54 AUX GND
- J1-55 +12 VDC
- J1-56 -12 VDC

J2 - MOLEX HEADER TO PS

- J2-1 +5 VDC
- J2-2 +5 VDC
- J2-3 GND
- J2-4 GND
- J2-5 NC
- J2-6 +12 VDC
- J2-7 NC
- J2-8 -12 VDC
- J2-9 NC

J3 - MOLEX HEADER TO BATTERY

- J3-1 +B VDC
- J3-2 +B VDC
- J3-3 GND
- J3-4 GND

10/6/01

P/N 0010-1431

BATTERY CHARGER/REGULATOR - PLL

HH

B-067