



INSTALL JUMPER ON PC BOARD 843 5400 043 IN PLACE OF CR1

<p>NOTES</p> <p>4. INDUCTANCE IN UH.</p> <p>3. CAPACITANCE IN UF.</p> <p>2. RESISTANCE IN OHMS.</p> <p>1. ALL RESISTORS ARE 1/2 WATT, 1%.</p> <p>UNLESS OTHERWISE NOTED:</p>	<p>6. 5% RESISTORS MAY BE SUBSTITUTED FOR ANY RESISTOR UNLESS LABELED 1% ON THIS DOCUMENT.</p> <p>5. SHEET NUMBER ZONE (2/A1) CONTINUATION SYMBOL</p>	REV	LTR	ZONE	DATE	DFTM	ENG	ECO NUM	<p><b>HARRIS</b></p> <p>HARRIS CORPORATION BROADCAST SYSTEMS P.O. BOX 4290 QUINCY, ILLINOIS 62305</p>	<p>DRAWN BY DFD</p>	<p>TITLE</p> <p>SCH AIRFLOW SENSOR</p>
		D			1-12-02	JPK	TLH	47924		<p>DATE 11-1-94</p>	
		C			12-1-00	RLB	RLB	46689		<p>ENG HOLLENBERG</p>	
		C								<p>PRJ HOLLENBERG</p>	
<p>CHANGE U2,U3,U4 TO TO220 PACKAGE</p>									<p>MFG ENG</p>	<p>DWG # 843-5400-041</p>	<p>REV D</p>

THIS DOCUMENT CONTAINS PROPRIETARY DATA OF HARRIS CORPORATION. NO DISCLOSURE, REPRODUCTION, OR USE OF ANY PART THEREOF MAY BE MADE EXCEPT BY WRITTEN PERMISSION.

DATE	11-1-94
ENG	HOLLENBERG
PRJ	HOLLENBERG
SHEET	1 OF 1

DWG #	843-5400-041
REV	D