

Complete Spare Parts List for TC-777 - 2 UL / - 2J(E)
4 UL / - 4J(E)

Common Parts

<u>Ref.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
<u>Mechanical Parts</u>			
A1	X-31030-23	Tension Arm (S) Ass'y, stabilizer -----	1
A2	-21	Arm Ass'y, pinch roller -----	1
A3	-27	Brake Band Ass'y, take-up; U type -----	1
A4	-28	Brake Band Ass'y, feed reel, U type -----	1
A5	-11	Tension Arm Ass'y, take-up -----	1
A6	-33	Damper Ass'y, tension arm -----	1
A7	X-31230-01	Arm Ass'y, tape shifter -----	1
A8	X-31030-07	Reel Table Ass'y, feed & take-up -----	2
A9	-16	Frame Ass'y, chassis foot -----	2
A10	Y-31038-02-1	Complete Cabinet Ass'y -----	1
A10-1	3-103-275	Sash, cabinet lid; aluminum -----	2
-2	-276	Sash, cabinet body; " -----	2
-3	-552	Handle Grip -----	1
-4	-553	Bracket, handle grip holder -----	2
-5	-554	Catcher, cabinet lid -----	2
-6	-555-04	Detachable Hinge -----	2
-7	-559	Ventilation Grille -----	1
-8	-560	Duct, ventilation Grille -----	1
-9	-570	Cabinet Foot, dark gray -----	2
-10	-571	Reel Retainer, cabinet lid -----	2
-11	-582	Badge, SONY -----	3
-12	-752	Frame, input jack -----	1
-13	-753	Frame, output jack -----	1
-14	-754	Frame, power supply -----	1
-15	-756	Cushion, cabinet body -----	2
-16	-758	Ventilation Grille (back side) -----	1
-17	-767	Belt, power cord holder -----	2
-18	-769	Plate, cabinet reinforcement -----	1
-19	-821	Plate, front grille, cabinet lid -----	1
-20	-822	Plate, front grille, cabinet body -----	1
-21	-823	Sash, cabinet lid, gray -----	2
-22	-206	Ornamental Washer, cabinet mounting -----	8
-23	-319	Plate, earth lug -----	1
-24	-360	Plate, cabinet spacer -----	2
-25	-862	Plate, fiber -----	1
-26	0-041-317	Plate, connector lid holder -----	1
-27	-318	Bracket, connector lid holder -----	1

Ref. No.	Part No.	Description	Q'ty
A10-28	0-041-321	Plate, power supply cord cover -----	1
-29	0-051-365	Cover, power supply -----	1
-30	3-107-613	Rubber Foot -----	8
-31	3-412-604	Sash Cover (A) -----	4
-32	-605	Sash Cover (B) -----	4
A11	X-31030-22-4	Connector Lid Ass'y -----	1
A12	-24-0	Knob Ass'y, line input level control -----	2
A13	-25	Knob Ass'y, playback level control -----	2
A14	X-31039-17	Knob Ass'y, Mic input level control -----	2
A15	-07	Bracket Ass'y, record switch holder -----	1
A16	X-31030-16	Frame Ass'y, chassis -----	2
1	3-103-022	Capstan Shaft Holder -----	1
2	-024	Dust Cap, capstan shaft -----	1
3	-025	Flywheel, capstan shaft -----	1
4	-103	Capstan Belt, wide -----	1
5	-105	Pin, capstan shaft holder -----	1
6	-112	Oil Ring, capstan shaft; felt -----	1
7	-120	Ring, metal holder -----	1
8	-260	Rearer, capstan shaft -----	1
9	-266	Ring, capstan shaft -----	1
10	-267	Paper Washer, capstan shaft; 16 ϕ -----	1
11	-274	Washer, flywheel, 8 ϕ -----	1
12	-277	Capstan Shaft -----	1
13	-278	Sleeve, capstan shaft -----	1
14	-282	Screw, sleeve holder -----	1
15	-963	Bearing Metal (S) -----	1
16	-964-00	Spacer, capstan shaft holder; 0.6t -----	3
17	-01	Spacer, capstan shaft holder; 0.3t -----	3
18	3-404-214 ⁰¹ / ₀₂	Motor Pulley, ^{-01 50%} / _{-02 40%} -----	1
19	3-409-108-01	Washer, nylon; reel panel; 0.5t -----	1
20	3-103-028	Cap (B), pinch roller -----	1
21	-029	Plate, pinch roller cap -----	1
22	-035	Joint Rod, solenoid -----	1
23	-036	Bracket, joint limiter -----	1
24	-106	Spring, joint rod pressure -----	1
25	-107	Spring, joint rod reset -----	1
26	-112	Oil Absorber, pinch roller -----	1
27	-114	Washer, joint rod; felt -----	1
28	-118	Washer, pinch roller arm; fiber -----	1
29	-127	Bracket, return spring stopper -----	1
30	-134	Washer, pressure spring stopper -----	2
31	0-027-058	Washer, adjustable -----	2
32	3-103-242	Washer, nylon; 6 ϕ -----	2
33	-262	Pinch Roller; rubber -----	1

<u>Ref.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
34	3-404-228	Pin, solenoid joint holder -----	1
35	3-103-316	Indicating Plate, input jack -----	1
36-1	3-103-722-02	Indicating Plate, output jack -----	1
37	3-103-273-01	Head Cover (S) -----	1
38	3-103-006	Pin, head cover holder -----	2
39	3-103-007	Plate, head apron -----	1
40	-013	Plate, head lead -----	1
41	-146	Spacer, connector holder -----	3
42	-238	Spring, tape guide, feed reel side -----	1
43	-239	Tape Guide Shaft (C) -----	1
44	-240	Tape Guide (C), feed reel side -----	1
45	-241	Tape Guide (D), take-up side -----	1
46	-293	Screw, head cover reset -----	2
47	-351	Plate, head holder -----	1
48	-352	Bracket, head shield plate -----	1
49	-353	Bracket, head shield cover -----	1
50	-354	Shield Case, 2 & 4 track p.b. head -----	2
51	-355	Plate, 2 & 4 track p.b. head adjustable -----	2
52	-356	Plate, ERP head adjustable -----	1
53	-357	Plate, ERP head holder -----	1
54	-366	Spring, head adjustable -----	3
55	-526	Bushing, head connector stopper -----	3
56	-729	Attaching Plate, head shield plate -----	1
57	-961	Screw, head adjusting -----	6
58	-965	Washer, head plate adjusting -----	3
59	3-005-001-60	Screw, ERP head adjusting -----	3
60	3-103-046	Stabilizer shaft -----	1
61	-051	Plate, stabi shaft holder -----	1
62	-052	Flywheel, stabilizer shaft -----	1
63	-053	Plate, stabilizer thrust support -----	1
64	-054	Screw, thrust support adjusting -----	1
65	-055	Spacer, thrust support -----	1
66	-056	Lock Nut, thrust adjusting -----	1
67	-110	Spring, stabilizer -----	1
68	-242	Washer, nylon 6/6; stabilizer shaft -----	1
69	-243	Shaft Holder, stabilizer -----	1
70	-249	Bracket, stabilizer spring hold -----	1
71	-250	Screw, spring hold bracket mounting -----	1
72	-251	Set Screw, stabilizer shaft -----	1
73	-253	Sleeve, stabilizer shaft holding -----	1
74	-261	Washer, stabilizer shaft holding -----	1
75	-280	Balancer (A), stabilizer -----	1
76	-281	Balancer (B), stabilizer -----	1
77	-367	Stopper, stabilizer -----	1

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
78	3-103-966	Spacer, stabilizer -----	1
79	7-621-113-01	Steel Ball, 3/8 -----	1
80	3-103-062	Plate, brake band mounting -----	2
81	-063	Brake Arm (A), take-up side -----	1
82	-066	Lug, brake spring mounting -----	2
83	-067	Bracket, solenoid mounting -----	1
84	-069	Damper, solenoid; rubber -----	1
85	-064	Brake Arm (B), feed reel side -----	1
86	-108	Brake Spring -----	2
87	-254	Bracket, solenoid mounting -----	1
88	-970	Screw, solenoid mounting -----	3
89	-971	Washer, " " -----	3
90	-116	Washer, brake arm, fiber -----	2
91	-205	Bracket, 2P connector holder -----	1
92	-071	Damper, push button (FWD, RWD, STOP REC) -----	4
93	-072	Shaft, push button -----	1
94	-073	Spacer, push button, sleeve -----	6
95	-074	Lug, push button mounter -----	2
96	-075	Screw, push button mounter -----	2
97	-076	Lug, push button mounter -----	3
98	-078	Damper, push button -----	5
99	-079	Switch, speed selector -----	1
100	-080	Bracket, speed selector switch holder -----	1
101	-252	Bracket, channel selector switch holder (S) -----	1
102	-255-02	Button, P.B. head selector, darkgray -----	8
103	-259-04	Button, RWD, FWD, F.F. selector, white -----	3
104	-05	Button, stop, darkgray -----	1
105	-959	Bracket, push button reset -----	3
106	3-404-207	Wire, channel selector switch adjustable -----	1
107	3-103-042	Lug, tension arm spring mounter -----	1
108	-111	Spring, tension arm -----	1
109	-116	Washer, 5/8 tension arm, fiber -----	2
110	-226	Tension Arm Boss (S) -----	1
111	-227	Bracket, micro switch holder -----	1
112	-298	Damper, tension arm -----	3
113	-018	Arm, shifter point -----	1
114	-126	Spring, shifter arm -----	1
115	-059	Screw, reel table setting -----	4
116	-086-04	Rubber Sheet, reel table; darkgray -----	2
117	-091-03	Printed Circuit Board, relay section -----	1
118	-093	Insulator, relay P.C.B. -----	1
119	-094	Cushion, relay P.C.B. -----	4
120	-211	Angle, relay P.C.B. holding -----	1
121	-082-12	Reel Panel, gray -----	1

Ref. No.	Part No.	Description	Q'ty
122	0-041-029	Washer, reel panel, 3/8	4
123	3-103-097-01	Printed Circuit Board, 4P terminal	1
124	-515	Spacer, control panel mounting, sleeve	4
125	-526	Bushing, bounting spacer	4
126	-087-04	Tape Index Counter, model M311	1
127	-088-01	Knob, tape index ounter	1
128	-089	cover, tape index counter	1
129	-090	Belt, tape index counter	1
130	-364	Badge, solid state, 777	1
131	0-007-313	Wire Retainer	3
132	3-107-086	Speed Nut, 3/8	1
133	3-103-755	Frame, power socket	1
134	3-103-514	Screw, connector holder	1
135	-288	Spacer, jack adjustable	5
136	-502	Bracket, micro switch holder	1
137	-506	Bracket, record button holder	1
138	-508-01	Cover, selector switch	1
139	-516	Plate, record button spring	1
140	-517	Spring, record button guard	1
141	-518	Spring, guard reset	1
142	-521	Record Button	1
143	-522	Record Button Guard (A)	1
144	-523	Record Button Guard (B)	1
145	-528	Cushion, control knob; felt	2
146	-531	Cushion, panel	4
147	-532	Insulator, selector switch	1
148	-537	Indicating Smet, control knob	2
149	-714-03	Bracket, chassis reinforcement	1
150	-04	Bracket, chassis reinforcement	1
151	-716	Bracket, capacitor holder	1
152	-718-04	Control Panel	1
153	2-029-928-	Heat Sink X501,502	2
154	3-103-308	Chassis, amplifier	1
155	-304	" , equalizer	1
156	-305	" , power supply	1
157	-310	" , bias oscillator	1
158	-326	Protecting Plate, power transformer holder	1
159	-141	Bracket, panel holder	2
160	-149	" , monitor switch holder	1
161	-270	Knob, line input level control	2
162	-271	Ornamental Sheet " "	2
163	-272	Felt, " "	2
164	-286	Fiber, insulator	1
165	-705	Spacer, power transformer	4

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
166	3-103-720	Plate, selector switch holder -----	1
167	-912	Guard, instant stop -----	1
168	-913	Push Button, instant stop -----	1
169	-915	Button Boss -----	1
170	-916	Bracket, switch holder -----	1
171	-917-01	Knob, mic input level control -----	2
172	-918-02	Ornamental Plate " " -----	2
173	-525	Glass, pilot lamp -----	2
174	-142	Felt, reel panel holder -----	2
175	-150	Insert Plate, record button -----	2
176	-953	Spring, instant stop button -----	1
177	-954	Bracket, switch stopper -----	1
178	0-041-223	Washer, 9.5ø jack spacer -----	7
179	0-050-061-04	Knob, mic input control -----	2
180	3-103-288	Washer, 9.5ø; jack adjustable -----	2
181	-301-04	Printed Circuit Board, equalizer -----	2
182	-302-03	" " " , amplifier -----	2
183	-303-02	" " " , 8 P connector -----	1
184	-311-01	" " " , bias adjustment -----	1
185	-312-03	" " " , power supply -----	1
186	-324-00	" " " , resistor holder -----	1
195	3-001-706-01	Wire retainer -----	
196	3-103-139-03	Hum-proof Belt, capstan motor -----	1
197	-289	" " , rotor -----	1
198	-365	Bracket, hum-proof held holder -----	1
199	-096	" " , remote connector -----	1
200	-130	Bracket, AC outlet holder -----	1
201	-058	Rod, relaying terminal holder -----	2
202	-143	Fiber, capacitor cover -----	1
203	-207	Bracket, capstan motor reinforcement -----	1
204	-363	Shield Case, connector (CN403) -----	1
205	-124	Bracket, chassis reinforcement -----	1
206	3-002-407	Spacer, 6ø; sleeve -----	2
	S1-P-0237	Instruction Manual -----	1
	7-491-001	Desiccant -----	1
	3-793-010-20	Tape Talk -----	1
	-030-00	Booklet, SONY tape -----	1
	3-998-911-00	Polishing Cloth -----	1
	3-103-182-04	Carton Box -----	1
	7-621-255-15	Screw (+) RF 2 x 3 -----	4
	-25	" (+) RF 2 x 4 -----	6
	-45	" (+) RF 2 x 6 -----	4
	-261-25	" (+) RF 3 x 4 -----	4
	-35	" (+) RF 3 x 5 -----	2

<u>Ref.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
	7-621-261-45	Screw (+) RF 3 x 6	42
	-52	" (+) RF 3 x 8	4
	-55	" (+) RF 3 x 8	17
	-65	" (+) RF 3 x 10	2
	-75	" (+) RF 3 x 12	3
	-83	" (+) RF 3 x 14	2
	-262-25	" (+) RF 3 x 20	5
	-55	" (+) RF 3 x 25	1
	-75	" (+) RF 3 x 35	2
	-268-55	" (+) RF 4 x 8	2
	-65	" (+) RF 4 x 10	5
	-73	" (+) RF 4 x 12	7
	-261-35	" (+) RF 4 x 35	11
	-555-42	" (+) K 2 x 6	6
	-46	" (+) K 2 x 6	2
	-559-25	" (+) K 2.6 x 4	1
	-561-45	" (+) K 3 x 6	1
	-62	" (+) K 3 x 10	2
	-655-16	" (+) RK 2 x 3	2
	-669-26	" (+) RK 4 x 20	8
	-56	" (+) RK 4 x 25	7
	-26	" (+) RK 4 x 20	1
	-776-26	" (+) B 3 x 6	4
	-461-42	" (+) T 3 x 6	4
	-715-47	Set Screw 4 x 6	2
	-36	" 4 x 6	2
	-35	" 4 x 6	2
	7-622-108-02	Nut 3 ϕ	14
	-309-02	" 3 ϕ	2
	-210-02	Lock Nut, 4 ϕ	2
	7-623-105-62	Washer, 2 ϕ (small)	1
	-105-12	" , 2 ϕ (middle)	3
	-110-12	" , 4 ϕ	2
	-205-12	Spring Washer 2 ϕ	8
	-308-05	Lock Washer 3 ϕ	8
	-410-05	Lock Washer 4 ϕ	28
	-408-05	Lock Washer 3 ϕ	84
	-508-01	Lug, 3 ϕ	1
	-510-01	Lug, 4 ϕ	1
	7-625-114-21	Rivet 3 x 4	4
	7-624-105-01	Retaining Ring, E2.3	2
	-110-05	" , E6	2
	-147-01	" , U3.2	3
	-148-05	" , U4	2

Ref. No.	Part No.	Description	Q'ty
	7-623-205-22	Spring Washer 3/6	3

Electrical Parts

		Transistor	2SB380	X101,103,107	6
		"	2SB380	X104,106	4
		"	2SB381	X102,109	4
		"	2SB382	X105,108	4
		"	2SC292	X501,502	2
		Diode	1S-124	D301,302	2
		"	5G-D	D501 - D504	4
187	82-1242-24	4 Track Playback Head		PP30-4202LNS	1
188	82-1228-21	2 Track Playback Head		PP30-2802LN	1
190	83-1634-05	Capstan Motor		HC-634D4 M301	1
191	83-2524-02	Reel Motor		IC-524R1 M302	1
192	83-6124-01	" "		UC-124R M303	1

Electrical Capacitor

1-121-002	100u	150V	C312	1
-192	10u	15V	C101,103,111,105,106,108, 113,120,121,122,125	12
-138	30u	15V	C114,116,119	3
-151	100u	25V	C102,112,117,123	4
-155	200u	10V	C118	1
-156	200u	25V	C127,504	2
-161	500u	6V	C104,110	2
-081	500u	15V	C124,126	2
-050	2000u	50V	C401	1
-351	30u	50V	C503	1
1-119-089	100u	150V	C318	1
-126	500u	25V	C502	1
-123	500u	35V	C501	1

Mylar Capacitor

1-105-822	0.0015u	50V	C130	1
-821	0.001u	50V	C115	1
-839	0.033u	50V	C109,128,206	3
-827	0.0033u	50V	C129,201,505,203	4
-829	0.0047u	50V	C133	1
-825	0.0022u	50V	C131,132,203	3
-837	0.022u	50V	C207,209	2

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
1-105-841	0.047u	50V	C208 ----- 1
-921	0.047u	200V	C210 ----- 1
-683	0.068u	50V	C204 ----- 1
-671	0.0068u	50V	C204 ----- 1
<u>Styrol Capacitor</u>			
1-103-487	500P	250V	C202 ----- 1
-489	2500P	250V	C508 TC-777-2 ----- 1
(-489	5000P	250V	C508 TC-777-4 ----- 1
<u>Trimmer Capacitor</u>			
1-141-034	30 - 200P		VC601,602 ----- 2
<u>Metalized Paper Capacitor</u>			
1-117-005	0.1u	250V	C308,321 ----- 2
1-113-020	4u	250V	C310,311 ----- 2
-109	0.1u	250V	C301,302,303,304,305,306, 307,313,314,315,316,320, 322,317 ----- 15
-021	2 + 0.5u	250V	C309 ----- 1
<u>Resistor, carbon</u>			
1-203-352	22	RD1/8RL	R135 ----- 1
-832	56	"	R124 ----- 1
-466	82	"	R140 ----- 1
-417	180	"	R121 ----- 1
-361	470	"	R106,130 ----- 2
-335	750	"	R116 ----- 1
-365	680	"	R105 ----- 1
-761	910	"	R119 ----- 1
-367	1K	"	R129,130,114,133,120 -- 5
-368	1.2K	"	R127,128,134 ----- 3
-405	1.5K	"	R111,136 ----- 2
-369	1.8K	"	R126 ----- 1
-370	2.2K	"	R134 ----- 1
-306	4.3K	"	R110 ----- 1
-408	8.2K	"	R115 ----- 1
-383	10K	"	R118,139 ----- 2
-385	15K	"	R113,117 ----- 2
-386	18K	"	R132 ----- 1

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
1-203-387	22K	RD1/8RL R131	1
-388	27K	" R107,108	2
-409	68K	" R115	1
-386	18K	" R201	1
-388	2.7K	" R202	1
-370	2.2K	" R209	1
-367	1K	" R207	1
-044	2K	RD1/4L R208	1
-027	560	" R137	1
-029	750	" R203	1
-151	1.8K	" R206	1
-100	100K	" R205	1
-093	43K	" R204	1
-367	1K	RD1/8RL R506	1
-960	5.6K	" R505	1
-757	2K	RD2L R504	1
-062	4.3K	RD1/4L R507,508	2
-999	12K	RD1/8RL Noiseless R109	1
-388	270K	" R141	1
1-204-217	36	RD1/2L R502,503	2
-216	1.6K	RD1/8RL R138	1
-490	30K	RD1/2SP R601,602	2
-916	18K	RD1/8RL Noiseless R101,122	2
-918	750	" " R104	1
-919	1.8K	" " R103	1
-920	6.2K	" " R102,123,125	3
1-207-051	10	1.5W R501	1
<u>Resistor, enameled</u>			
1-205-008	150	5W R302	1
-172	750	" R305,306	2
-420	20 + 80	R303	1
1-227-037	100	R413	1
<u>Resistor, wire wound</u>			
1-207-076	360	R411	1
-082	150	R412	1
<u>Resistor, solid</u>			
1-201-240	600	RC1/4 R404,407	2
-019	1K	" R403,408	2

Ref. No.	Part No.	Description	Q'ty
	1-201-030	3.3K RC1/4	R405, 406 ----- 2
	-429	3.6K "	R402, 409 ----- 2
	-244	68K "	R401, 410 ----- 2
	-263	500K "	R301 ----- 1
<u>Resistor, adjustable</u>			
	1-221-145	10K (A)	VR201, 202, 203 ----- 3
	-144	10K (C)	VR204, 205, 206 ----- 3
<u>Potention Meter</u>			
	1-221-142	50K (D), 10K (D) Mic. Input Level,	
	-269	10K (A)	VR401, 402, 403, 404 ----- 4
		<u>Coil</u>	VR405, 406 ----- 2
	1-421-042	Trap & Equalizer, 1mH	L101, 202 ----- 2
	-043	Equalizer 4mH	L203, 204 ----- 2
	1-409-037	Trap 8mH	L201 ----- 1
	-063-12	Bias Adjust 1mH	L601, 602 ----- 2
	1-515-025	Relay, 4 pole, 24V	RY201 ----- 1
	-026	" , 4 " , 45V	RY401 ----- 1
	-001	" , play, stop F. forward	RY301, 302, 303 -- 3
	1-429-128	Output Transformer	T101 ----- 2
	1-423-076-12	Driver Transformer	T401, 402 ----- 2
	1-433-066	Bias Oscillator Transformer	T501 ----- 1
	1-441-155-12	Power Transformer	T403 ----- 1
	1-513-183	Mic. Sensitivity Selector Switch	S401 ----- 1
	-149	Output Impedance Change Switch	S402 ----- 1
	-160	Monitor Switch	S403, 404 ----- 2
	1-514-146	Track Selector Switch	S405 ----- 1
	-068	Record Selector Switch	S406 ----- 1
	-057	Instant Stop Switch	S308 ----- 1
	-059	Channel Selector Switch	S408 ----- 1
	-140-12	Power Switch	S409 ----- 1
	-057	Speed Selector Switch	S301 ----- 3
	-058	Stop Switch	S304 ----- 1
	-059	F. Forward, Rewind, Play Switch	S303, 305, 306 - 3
	-110	Micro Switch	S302 ----- 1
	1-533-007-00	Little Fuse Mounting	F302 ----- 1
	1-533-048-11	Extractor Post	F301 ----- 1
	1-533-006	Fuse Mounting	F501 ----- 1
	1-532-014	Fuse 0.8A	F501 ----- 1

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
	1-532-018	Fuse 2.5A F301 -----	1
	-029-11	Fuse 0.3A F302 -----	1
	1-518-024	Pilot Lamp (100V) -----	1
	1-517-003	Pilot Lamp Socket -----	1
	1-507-107	Line Input Jack J401,402 -----	2
	-108	Line Output Jack J403,404 -----	2
	-136	Binaural Monitor Jack J-405 -----	1
	1-509-046	Microphone Input Jack CN401,402 -----	2
	-035	Receptacle Connector 8P (female) CN403 -----	1
	-033	Receptacle Connector 11P(female) CN404 -----	1
	-042	Receptacle Connector 2P (female) CN405 -----	1
	-035	Receptacle Connector 8P (female) CN406 -----	1
	-039	Receptacle Connector 8P (male) CN501 -----	1
	-018	4P Baby Connector CN325 -----	1
	-019-01	AC Connector 2P (female)CN307 -----	1
	-019-02	AC Connector 2P (male) CN308 -----	1
	-038	Receptacle Connector 11P (Male) CN321 -----	1
	-041	AC Cord Connector CM311 -----	1
	-043	Receptacle Connector 8P (male) CN322 -----	1
	-013	AC Input Connector 2P (male) CN306 -----	1
	-015-01	AC Outlet Socket CN309,310 -----	2
	-031-02	Receptacle Connector 8P w/ remote control switch CN305 -----	1
	-035	Receptacle Connector 8P (Female) CN301 -----	1
	1-454-002-02	Pinch Roller Solenoid PM301 -----	1
	-003-02	Brake Solenoid PM302 -----	1
	1-536-013	Terminal Strip 2L-4P -----	4
	-014	Terminal Strip 1L-3P -----	1
	-038	Terminal Strip 6P -----	2
	-061	Terminal Strip 1-L-1 -----	1
	1-520-042	Volume Unit Meter M401,402 -----	2

Exclusive Parts

TC-777-2UL(Additional)

189	82-7600-00	Erase/Record Head, ERP24-2202 -----	1
193-1	3-103-285-05	Name Plate, serial number stamped -----	1
194-1	-317-01	Indicating Plate, 777-2UL -----	1

TC-777-4UL (Additional)

189	82-7600-10	Erase/Record Head, ERP24-2902 -----	1
193-2	3-103-285-06	Name Plate, serial number stamped -----	1
194-2	-317-02	Indicating Plate, 777-4UL -----	1

12/12_(U)(TC777-2/-4UL)

C7-1

Complete Spare Parts List for TC777-2J (Additional)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
193-3	3-103-857-02	Name Plate, serial number stamped -----	1
	-859-01	Badge, solid state 777-2J -----	1
	X-31038-08-4	Carton Box Ass'y -----	1
A10	Y-31038-02-0	Complete Cabinet Ass'y -----	1
35	3-103-809	Indicating Plate, input jack -----	1
36-2	-722-03	" " , output jack -----	1
194-1	-321-01	" " , 777-2J -----	1
133	-858	Frame, power socket -----	1
	S1-P-0287-11	Instruction Manual -----	1
	1-441-245-12	Power Transformer T501 -----	1
	1-509-064	Socket, voltage selector -----	1
	1-201-039	Resistor, solid; 10K R403,408 -----	2
	-059	" " ; 100K R402,409 -----	2
	1-514-146-13	Switch, push S401 -----	1
	-068	Switch S405 -----	1
	-059	" S406 -----	1
	-140	" S407 -----	1
	1-507-108	Jack, E type J406,407 -----	2
	1-509-029	Connector, Pin (female) CN401 -----	1
	-039	" , 8P (male) CN402 -----	1
	-033	" , 11P (female) CN403 -----	1
	-042	" , AC cord CN404 -----	1
	-035	" , 8P (female) CN405 -----	1
	1-203-128	Resistor, carbon 12K RD $\frac{1}{2}$ L R105 -----	1
	-095	" " 47K " R151 -----	1
	-316	" " 510 RD1/8R R111 -----	1
	1-514-142-11	Power Cord -----	1
	3-103-820-10	Accessory Bag -----	1
	91-0911-30	Head Set, DR-1C -----	1
	1-534-063	Connection Cord, RK-55 -----	2
	-266	" " , RC-2 -----	1
	8-811-810-21	Microphone, F-81 (LQ) -----	2
	Y-20161-01	SONY Oil -----	1
	8-852-171	Tape, S-7 -----	1
	8-860-071	Reel,R-7A -----	1

Complete Spare Parts List for TC777-4J (Additional)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Q'ty</u>
193-4	3-103-857-01	Name Plate Serial Number Stamped -----	1
	-859-02	Badge, solid state, 777-4J -----	1
	X-31038-08-4	Carton Box Ass'y -----	1
A10	Y-31038-02-0	Complete Cabinet Ass'y -----	1
35	3-103-809	Indicating Plate, input jack -----	1
36-2	-722-03	" " , output jack -----	1
194-2	-321-02	" " , 777-4J -----	1
133	-858-	Frame, power socket -----	1
	S1-P-0287-11	Instruction Manual -----	1
	1-441-245-12	Power Transformer T501 -----	1
	1-509-064-	Socket, voltage selector -----	1
	1-201-039	Resistor, solid, 10K R403,408 -----	2
	-059	" " 100K R402,409 -----	2
	1-514-146-13	Switch, push S401 -----	1
	-068	" " S405 -----	1
	-059	" " S406 -----	1
	-140	" " S407 -----	1
	1-507-108	Jack, E type J406,407 -----	2
	1-509-029	Connector, pin (female) CN401 -----	1
	-039	" , 8P (male) CN402 -----	1
	-033	" , 11P (female) CN403 -----	1
	-042	" , AC cord CN404 -----	1
	-035	" , 8P (female) CN405 -----	1
	1-203-128	Resistor, carbon, 12K RD $\frac{1}{2}$ L R105 -----	1
	-095	" " 47K " R151 -----	1
	-316	" " 510 RD1/8R R111 -----	1
	1-514-142-11	Power Cord -----	1
	3-103-820-10	Accessory Bag -----	1
	91-0911-30	Head Set DR-1C -----	1
	1-534-063	Connection Cord, RK-55 -----	2
	-266	" " , RC-2 -----	1
	80811-810-21	Microphone, F-81 (LQ) -----	1
	Y-20161-01	SONY Oil -----	1
	8-852-171	Tape, S-7 -----	1
	8-860-071	Reel, R-7A -----	1